

Documentation



MastMinder®

Site Installation Guide

F400e Generic

(single generator)
(single fuel tank)

Revision 2
January 2017

MastMinder Ltd
Alphamstone
Bures
Suffolk
CO8 5HH
United Kingdom

Tel: +44 (0) 1787 269018
info@MastMinder.com

Warranty

MastMinder Limited has made every effort to ensure the accuracy of the content of this manual. However, it is possible that it may contain technical inaccuracies or typographical or other errors.

MastMinder Limited will assume no liability for any inaccuracy found in this publication, nor for damages, direct, indirect, incidental, consequential or otherwise, that may result from such an inaccuracy, including without limitation loss of data or profits.

MastMinder Limited provides this manual “as is”, and does not issue a warranty of any kind, express or implied, including without limitation implied warranties of merchantability or fitness for a particular purpose.

The information provided in this manual is subject to change without notice. MastMinder Limited reserves the right to alter product designs or specifications without notification.

MastMinder® is a registered trademark of MastMinder Limited.

This document should be read in conjunction with the MastMinder F400e User Guide.

Table of Contents

1.	MastMinder Site Installation Kit – Inventory of components	4
2.	Tools required to perform the installation.....	5
3.	F400e Master Unit Positioning.....	6
4.	F400e Outline Drawing	6
5.	LED Indicators	7
6.	Power and I/O Signal Connections	8
7.	Network Connection.....	9
7.1	Network LED indicators	9
8.	Generator Interface Module	10
8.1	Generator Interface Module Installation	10
9.	Fuel Level Sensor Installation	11
10.	Reading and Setting I/O Values and Parameters.....	12
10.1	F400e Unit Parameters.....	13
11.	Remote WEB Access.....	18
12.	System Console Port.....	20
12.1	Local terminal connection	20
12.2	Console Port Commands	20
12.2.1	<i>Console Command Reference</i>	21
13.	F400e Master Unit Connections – generic.....	22
14.	F400e Master Unit Connection Schedule – generic.....	23

1. MastMinder Site Installation Kit – Inventory of components

The following components are provided in the MastMinder F400e Site Installation kit for single generator.

- 1 x F400e Master Control Unit
- 1 x Generator Alarm Status capture module
- 1 x Fuel Level Sensor and cable
- 1 x Inline Fuse Holder and Fuse
- 1 x 2.5mm flat screwdriver

Please check all these components are supplied in the kit and familiarise with the equipment, a picture of each of the major components is provided below.



F400e Master Control Unit



Fuel Level Sensor and cable Status capture module



2. Tools required to perform the installation


- Laptop with GPRS Web connection for Skype & TeamViewer for remote support, with good batteries and/or spares.
- Laptop with RJ45 and Ethernet cable for LAN connection direct to unit or local switch on site
- Mobile phone with good battery
- Flashlight with good battery
- Tape measure to measure tank dimensions and depth of fuel.
- Accurate Voltmeter (preferably with AC current clamp on top)
- Basic electric installation toolkit:
 - Wire cutters
 - Screw drivers of various heads
 - Etc.
- This Installation Manual
- Enough flexible plastic conduit pipe, if required, to protect any external cables running between the shelter and the generators and also the generator to the fuel tank.
- Selection of cable-ties.

3. F400e Master Unit Positioning

The base unit is housed in a DIN rail mountable aluminium enclosure. The unit can be mounted in any orientation but must be installed in a dry area. *The MastMinder F400e unit is not designed to be installed in any outside location where it could be exposed to weather or water.*


An outline drawing showing the mounting details is shown below.

4. F400e Outline Drawing



5. LED Indicators

The Unit has five LED indicators located on the front of the unit:



The LED functions are shown in the table below.


GREEN (Power)	RED (Status)	YELLOW Outputs	Meaning
○	○	⊗	Unit not powered up
●	*	⊗	Normal Start up
●	*○*○...	⊗	Self test fail
●	** (10 sec)	⊗	System active
●	⊗	○	Output Not Active
●	⊗	●	Output Active

LED symbol key

- - LED On
- - LED Off
- * - LED Flash
- * (1 sec) - LED repeating flash (repetition rate)
- ⊗ - Don't care

6. Power and I/O Signal Connections

All power and IO signal connections to the master unit are made via 3.5mm plug-in terminal blocks.




The table below shows the IO connection allocations.

F400e Term.	Direction	Description
1	-	Ground (0V)
2	In/Out	1-Wire Interface
3	Out	1-Wire 3.3V Power Supply
4	In	Digital Input 1
5	In	Digital Input 2
6	In	Digital Input 3
7	In	Digital Input 4
8	In	Digital Input 5
9	In	Digital Input 6
10	In	Digital Input 7
11	In	Digital Input 8
12	-	Ground (0V)
13	-	Output 4, NO Relay Contact
14	-	Output 3, NO Relay Contact
15	-	Output 2, NO Relay Contact
16	-	Output 1, NO Relay Contact
17	-	Output 1, NC Relay Contact
18	-	Output 1, Common Relay Contact
19		Outputs 2,3,4 Common Relay Contact
20	-	Ground (0V)
21	-	Ground (0V)
22	In	4-20mA Level Sensor Input
23	Out	Level Sensor Filtered Supply Output
24	In	6-30VDC Power Input
25	-	Ground (0V)

7. Network Connection

The F400e can be connected to an Ethernet 10baseT or 100baseTX Ethernet network via the standard RJ45 network connector located in the top of the unit.



7.1 Network LED indicators

There are two LED indicators provided on the network connector.

The Yellow LED is lit if the unit is connected to a 100baseTX network.

The Green LED is lit if the network connection is active and will flash when network data is sent or received.


8. Generator Interface Module

In order to provide compatibility to many different generator and AMF equipment types the MastMinder Generator Interface Module can be used.

The generator interface module senses the generator mains and load current and provides the "Generator Ready" and "Generator On-Load" signals to the F400e unit.

Note that the "Generator On Load" signal is obtained by a circuit in series with the "Generator Running" signal and the Generator On Load auxiliary contacts from the ATS.

Note that the "Grid On Load" signal is obtained from the Current Sensor on the Generator Interface Unit which is normally used for Generator On Load.



8.1 Generator Interface Module Installation

1. Locate main generator output circuit breaker.
2. Connect the open clamp current transformer around the Neutral cable to signify current passing and "On Load" ..
3. Connect the interface module L1 and N connections to the phase and neutral on the **supply** side of the circuit breaker to signify voltage coming from generator and "Generator Running".
4. Connect the three output signals from the plug-in connector to the F400e digital inputs.
5. Secure the interface module in a convenient location using self tapping screws, 4mm bolts or cable ties.


9. Fuel Level Sensor Installation

The level sensor is designed to be situated on the bottom of the inside of the fuel tank. As standard the level sensor is supplied with 3 or 6 Metres of special vented cable.

The fuel tank must be examined to find a suitable way of inserting the sensor so it lies flat on the bottom of the tank and the cable is fed back out of a suitable hole or breather pipe. Sometimes this may involve removing an inspection plate or feeding the sensor in through the main filler hole and then feeding the cable back out through a suitable breather pipe.

There is no general rule here as all fuel tanks come in different shapes and sizes and sometimes a little ingenuity is required in order to install the sensor.

The general arrangement is shown below:



Typical installation:

Terminate the level sensor cable in the IO module according to the connection table below:

IO Module Term.	Dir.	Description	Dest.	Wire Col.	Destination Signal
14	In	4-20mA Current Loop Analogue Input	LEVEL	White	Level Sensor 4-20mA O/P
33	Out	8-16VDC Filtered Output	LEVEL	Brown	Level Sensor Power +12V
34	-	Power Ground	LEVEL	Green and Pink	Level Sensor GND

Important Note:

There is a black protective plug on the connector end of the vent tube to stop debris from entering during transport and storage, remove the black cap during installation for proper functioning.

The level sensor cable contains a vent tube. To ensure proper operation of the vent tube there must be no "kinks" or sharp bends in the cable run. **The minimum bend radius is 60mm.**



10. Reading and Setting I/O Values and Parameters

All system input measured variables and conditions, output states and system control variables are accessed through system “parameters”

Each parameter has a unique 3 character ID and are detailed in the section “System Parameter Reference”

Note: See Console Command Reference in User Manual for more detailed information on specific commands.

10.1 F400e Unit Parameters

Param ID	Type	Attributes	Length	Description
-- System Parameters --				
901	ROM	RW	20	Site ID 20 character string for system identification <i>Default = Site Name</i>
902	ROM	RO	4	Firmware Rev. Format n.nn
903	ROM	RO	20	Module Type '9045-V01 F400e'
913	ROM	RW	6	Admin Password Up to 6 character full access password. The password is disabled when the string is empty. <i>Default = None</i>
930	EROM	RW	4	Sent SMS Message Counter Keeps a count of the number of SMS messages successfully sent.
931	EROM	RW	4	SMS Message Number SMS Message serial number
950	RAM	RW	2	RTC Hours Real-time clock hour
951	RAM	RW	2	RTC Minutes Real-time clock Minute
952	RAM	RW	2	RTC Seconds Real-time clock Second
953	RAM	RW	2	RTC Years Real-time clock day
954	RAM	RW	2	RTC Months Real-time clock month
955	RAM	RW	2	RTC Days Real-time clock year
956	RAM	RW	12	RTC Time & Date Real-time clock hhmmssddmmyy
9XN	EROM	RO	5	Unit Serial Number 000D0640nnn Unit serial number
9U0	RAM	WO	1	System Reboot Writing any value to this parameter will cause the system to reboot
9u0	RAM	WO	1	Soft System Reboot Writing any value to this parameter will cause the system to reboot but preserve RAM parameter values.
9H0	EROM	RW	8	Hours Counter 0 Non-volatile total hours counter of the form HHHHH:MM. Counts total time Param 9U9=9 (system active, rule processing on)
9H1	EROM	RW	8	Hours Counter 1 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 1 is active.
9H2	EROM	RW	8	Hours Counter 2 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 2 is active.
9H3	EROM	RW	8	Hours Counter 3 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 3 is active.
9H4	EROM	RW	8	Hours Counter 4 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 4 is active.
9H5	EROM	RW	8	Hours Counter 5 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 5 is active.
9H6	EROM	RW	8	Hours Counter 6 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 6 is active.
9H7	EROM	RW	8	Hours Counter 7 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 7 is active.
9H8	EROM	RW	8	Hours Counter 8 Non-volatile total hours counter of the form HHHHH:MM. Counts total time input 8 is active.
9H9	EROM	RW	8	Network Down Time Non-volatile total hours counter of the form HHHHH:MM. Counts total time the GSM network is unavailable.

Param ID	Type	Attributes	Length	Description	
--Network Parameters --					
9e1	EROM	RW	16	Unit IP Address	nnn.nnn.nnn.nnn
9e2	EROM	RW	16	Unit IP Subnet Mask	nnn.nnn.nnn.nnn
9e3	EROM	RW	16	Unit IP Gateway Address	nnn.nnn.nnn.nnn
9e4	EROM	RW	16	Message Gateway Server IP Address	nnn.nnn.nnn.nnn
9e5	EROM	RW	5	Unit HTTP Port Number	nnnn (default 80)
9e6	EROM	RW	16	Unit HTTP Username	
9e7	EROM	RW	16	Unit HTTP Password	
9e8	EROM	RW	5	Message Gateway Server Port Number	nnnn (default 30303)
9GD	ROM	RW	16	FTP Server IP Address	nnn.nnn.nnn.nnn
9GE	ROM	RW	16	FTP Username	
9GF	ROM	RW	16	FTP Password	
9GG	ROM	RW	24	Download Filename	(must have .cff, .cpf or cwf extension)
9GZ	ROM	RW	1	Start File Download	Set to any value to start download
915	RAM	RO	10	IP Network Status	Status of IP Connection "UP" or "DOWN"
-- Rule Processing Parameters --					
9U9	ROM	RW	1	Rule Processing Enable	Set to "9" to enable rule processing, all other values disable rule processing. <i>Default: "0"</i>
-- 36 Rule Enable Parameters --					
9E0 - 9EZ	ROM	RW	1	Rule Enable	Enables/disables processing rule. 'Y' = enabled, 'N' = Disabled <i>Default = N (disabled)</i>
-- 36 user defined processing rules --					
9P0 - 9PZ	ROM	RW	160	Rule Body	String containing the rule directives <i>Default = none</i>
-- 36 rule qualify times --					
9Q0 - 9QZ	ROM	RW	4	Rule Qualify Time	Qualification time in seconds between a matching condition and the rule being triggered. 0-9999 <i>Default = 0</i>
-- 36 rule rearm times --					
9R0 - 9RZ	ROM	RW	4	Rule Rarm Time	Time in minutes to re-enable a triggered rule. 0-9999 <i>Default = 0</i>
-- 36 current rule status --					
9S0 - 9SZ	RAM	RO	8	Rule Status	Off - Not enabled Activ - Rule enabled, not triggered (no condition active) PreTrig - Unqualified Trigger Condition Trig - Rule triggered PreUTrig - Unqualified Un-Trig. Condition Rearmed - Rule triggered, re-armed (no condition active) Trig,R - Rearmed, still triggered
9IR	RAM	RW	1	Invalid Rule	Null if no rule syntax errors. Will contain rule number 0-9 or A-Z if invalid rule found
9WW	ROM	RW	16	Parameter File Version	Current Parameter File Version
9M0-9MV	ROM	RW	160	User Messages	User defined 'canned' Message. Message can contain parameter 'tags' allowing dynamic data to be included in the message. Messages can consist entirely of Parameter tags.

Param ID	Type	Attributes	Length	Description			
-- I/O Parameters --							
9I1	RAM	RO	1	Digital Input 1	Logical value of digital input 1, '0' or '1'		
9I2	RAM	RO	1	Digital Input 2	Logical value of digital input 2, '0' or '1'		
9I3	RAM	RO	1	Digital Input 3	Logical value of digital input 3, '0' or '1'		
9I4	RAM	RO	1	Digital Input 4	Logical value of digital input 4, '0' or '1'		
9I5	RAM	RO	1	Digital Input 5	Logical value of digital input 5, '0' or '1'		
9I6	RAM	RO	1	Digital Input 6	Logical value of digital input 6, '0' or '1'		
9I7	RAM	RO	1	Digital Input 7	Logical value of digital input 7, '0' or '1'		
9I8	RAM	RO	1	Digital Input 8	Logical value of digital input 8, '0' or '1'		
9J1	ROM	RW	1	Digital Input Level 1	Active level of digital input 1 (0,1 or -)		
9J2	ROM	RW	1	Digital Input Level 2	Active level of digital input 2 (0,1 or -)		
9J3	ROM	RW	1	Digital Input Level 3	Active level of digital input 3 (0,1 or -)		
9J4	ROM	RW	1	Digital Input Level 4	Active level of digital input 4 (0,1 or -)		
9J5	ROM	RW	1	Digital Input Level 5	Active level of digital input 5 (0,1 or -)		
9J6	ROM	RW	1	Digital Input Level 6	Active level of digital input 6 (0,1 or -)		
9J7	ROM	RW	1	Digital Input Level 7	Active level of digital input 7 (0,1 or -)		
9J8	ROM	RW	1	Digital Input Level 8	Active level of digital input 8 (0,1 or -)		
9V1	RAM	RO	4	Main Supply Value	Measured value of external supply, nn.n Volts		
9V2	RAM	RO	4	POE Supply Value	Measured value of Power over Ethernet supply, nn.n Volts		
9V5	RAM	RO	3	4-20mA (Level Sensor)	Measured value of external 4-20mA input , 0-255		
9VB	RAM	RO	4	5V Supply Value	Measured value of 5V internal supply, n.n V		
9U2	RAM	RW	1	Digital Input Change	Set to "1" if any digital input changes state. Remains set until cleared by user.		
9U3	RAM	RW	1	Analogue Input Status Change	Set to "1" if any analogue input changes state. Remains set until cleared by user.		
9X1	ROM	RW	1	Digital Output Value	Value of digital output , '0' or '1' This output controls a C/O relay.		
9X2	ROM	RW	1	Digital Output Value	Value of digital output , '0' or '1' This output controls a N/O relay.		
9X3	ROM	RW	1	Digital Output Value	Value of digital output , '0' or '1' This output controls a N/O relay.		
9X4	ROM	RW	1	Digital Output Value	Value of digital output , '0' or '1' This output controls a N/O relay.		
9T1	ROM	RW	4	Digital Output 1 Timer	Optional time in minutes for output to remain in current state before automatically returning to previous state. 0-9999 minutes. A value of '0' disables the timer function and the output remains unchanged.		
9T2	ROM	RW	4	Digital Output 2 Timer	As for 9T1		
9T3	ROM	RW	4	Digital Output 3 Timer	As for 9T1		
9T4	ROM	RW	4	Digital Output 4 Timer	As for 9T1		
9WM	RAM	RW	4	User Seconds Timer 1	User Programmable 4 digit seconds counter 0000-9999 seconds. Counts down from set value and stops at 0000		
9WN	RAM	RW	4	User Seconds Timer 2	User Programmable 4 digit seconds counter 2		
9U4	RAM	RW	4	User Minute Timer 1	User Programmable 4 digit minutes counter 0000-9999 minutes. Counts down from set value and stops at 0000		
9U5	RAM	RW	4	User Minute Timer 2	User Programmable 4 digit minutes counter 2		

Param ID*	Type	Attributes	Length	Description
-- Fuel Monitoring Parameters --				
9L1	EROM	RW	1	Level Sensor Type Level Sensor Type: 0=Ultrasonic Sensor 1=L400 2M 2=L400 4M 3=L400 10M
9L2	EROM	RW	4	Fuel Specific Gravity Specific gravity of fuel. Usually between 0820 and 0950 for diesel. Default = 0880
9L3	EROM	RW	1	Tank Type Type of Tank: 1=Linear (cuboid or cylinder on end) 2=Cylinder on it's side 3=User defined tank profile
9L4	EROM	RW	4	Tank Diameter Diameter of tank in mm, 4 digits long. (only needed for tank type 2)
9L5	EROM	RW	4	Maximum Useable Level Maximum useable level in mm, 4 digits.
9L6	EROM	RW	4	Minimum Useable Level Minimum useable level in mm, 4 digits.
9L7	RAM	RO	4	Measured Level Current measured level in mm
9LA-9LP	EROM	RW	4	User Level Entries 16 user defined level entries. Only used for tank type 3. As few (min 0) or as many (max 16) can be used in order to define tank level capacity characteristics. Entries are in mm and must be 4 digits long (leading 0's required)
9CA-9CP	EROM	RW	2	User Capacity Entries 16 user defined capacity entries. Only used for tank type 3. As few (min 0) or as many (max 16) can be used in order to define tank level capacity characteristics. Each entry is paired with corresponding level entry. Entries are in % of full capacity and must be 2 digits long (leading 0's required)
9F1	RAM	RO	5	Fuel Consumption Fuel consumption in units/hour. Only updated while engine is running (digital input 1 is active). Format nn.nn
9F2	RAM	RO	5	Average Fuel Cons. Average fuel consumption in units/hour over last 32 hours of engine running Format nn.nn
9F3	RAM	RO	1	Consumption Alarm Value "0" = no alarm, "1" = alarm, "2" = fuel Added Engine Running: Alarm is active if current fuel consumption exceeds average fuel consumption by more than the margin set in parameter 9F4. Or If fuel consumption is > 5 units/hour more than the margin set in parameter 9F4 Engine Stopped: Alarm is active if fuel level decreases by more than the margin set in parameter 9F4
9F4	ROM	RW	5	Fuel Margin Fuel consumption/level alarm margin in units. nn.nn
9F5	EROM	RW	1	Shared Fuel Tank Set to "1" if another generator is able to use the monitored fuel tank.

Param ID	Type	Attributes	Length	Description
-- User Parameters --				
9U1	RAM	RW	1	User Parameter
9WC	RAM	RW	6	User Parameter
9WD	RAM	RW	6	User Parameter
9WE	RAM	RW	6	User Parameter
9WF	RAM	RW	6	User Parameter
9WG	RAM	RW	8	User Parameter
9WH	RAM	RW	8	User Parameter
9WI	RAM	RW	8	User Parameter
9WJ	RAM	RW	8	User Parameter
9WO	RAM	RW	8	User Parameter
9WP	RAM	RW	12	User Parameter
9WU	EROM	RW	2	User Parameter
9WV	EROM	RW	2	User Parameter
9W1	EROM	RW	8	User Parameter
9W2	EROM	RW	8	User Parameter
9W3	EROM	RW	8	User Parameter
9W4	EROM	RW	8	User Parameter
9W5	EROM	RW	8	User Parameter
9W6	EROM	RW	8	User Parameter
9KA	EROM	RW	2	User Parameter
9W8	EROM	RW	16	User Parameter
9WX	EROM	RW	16	User Parameter
9U6	ROM	RW	1	User Parameter
9U7	ROM	RW	1	User Parameter
9UA	ROM	RW	4	User Parameter
9UB	ROM	RW	4	User Parameter
9UC	ROM	RW	4	User Parameter
9UD	ROM	RW	4	User Parameter
9UE	ROM	RW	4	User Parameter
9UF	ROM	RW	4	User Parameter
9UG	ROM	RW	4	User Parameter
9UH	ROM	RW	4	User Parameter
9UI	ROM	RW	4	User Parameter
9UJ	ROM	RW	4	User Parameter
9UK	ROM	RW	4	User Parameter
9UL	ROM	RW	2	User Parameter
9UM	ROM	RW	2	User Parameter
9WQ	ROM	RW	32	User Parameter
9WR	ROM	RW	10	User Parameter
9WS	ROM	RW	8	User Parameter
9WT	ROM	RW	4	User Parameter
9WW	ROM	RW	16	User Parameter
9UO	ROM	RW	4	User Parameter
9UP	ROM	RW	4	User Parameter
9UQ	ROM	RW	4	User Parameter
9UR	ROM	RW	4	User Parameter
9US	ROM	RW	4	User Parameter
9UT	ROM	RW	4	User Parameter
9UU	ROM	RW	4	User Parameter
9UV	ROM	RW	4	User Parameter
9UW	ROM	RW	4	User Parameter
9UX	ROM	RW	6	User Parameter
9UY	ROM	RW	4	User Parameter
9UZ	ROM	RW	4	User Parameter

11. Remote WEB Access

The F400e has an onboard web server which gives access to a number of the major parameters and interfaces on the F400e.

Web access is from a web browser.

Three pages are available through this interface as follows:

Main home page:

 MastMinder
www.mastminder.com

MastMinder F400e

Site Name: GTAT Site 102

Type	9045-V01 F400e	Firmware Revision	4.02										
Ethernet Address	000D06400038	Parameter File Version	GTAT Site 101 V1										
		<input type="button" value="Reboot"/>	<input type="button" value="Download"/>										
Site Name	GTAT Site 102												
IP Address	192.168.0.102	HTTP Port Number	80										
Subnet Mask	255.255.255.0	HTTP Username	mastminder										
Gateway IP Address	192.168.0.1	HTTP Password	M400e										
Message Server IP Address	192.168.0.78	Download Server IP Address	192.168.0.2										
Download Filename	GTandT F400E V1.cpf												
Date/Time	23	:04	:15	:13	:07	:40	<input type="button" value="Submit"/>						
Supply	12.0V	Input Qual Time	2	1	2	3	4	5	6	7	8		
PoE Supply	---V	Input Config	<input type="button" value="Submit"/>	1	1	0	0	0	0	0	0		
Internal Volts	4.9V	Input Value	1	1	0	0	0	0	0	0	0		
4-20mA Input	59	Outputs	<input type="button" value="Submit"/>	0	0	0	0	0	0	0	0		
Fuel Level	0332 mm	Consumption c/h	12.25	Ave Consumption c/h	08.81								
Sensor Type	1	Tank Height	1150	Fuel Alarm	1								
Tank Type	2	Max Fill Level	1150	Threshold	04.00								
Fuel Sg	0840	Min Fill Level	0025										
Shared Tank	0	Height@20mA	2039			<input type="button" value="Submit"/>							
System Active	9	Invalid Rule	<input type="button" value="▼"/>				<input type="button" value="Submit"/>						
Console Rule Settings													

MastMinder Ltd
Cranfields
Alphamstone
Bures Suffolk UK
CO8 5HH

email CliffWhitehead@MastMinder.com
Tel +44 (0)1787269018

Copyright © Mastminder Ltd.

Rule & Message Page:



MastMinder F400e

Site Name: GTAT Site 102

Param File Version: GTAT Site 101 V1

Rule 0	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 60	Rearm 0	<input \$1\"="" %9i2='\"\$0\"' %9i5='\"\$1\"' %9ul='\"\$1\""/' and="" or="" type="text" value="if %9X1=\"/> <input type="checkbox"/>
Rule 1	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$0\"="" %9i2='\"\$1\"' %9u1='\"\$1\""/' %9ul='\"\$0\"' and="" set="" then="" type="text" value="if %9UL=\"/> <input type="checkbox"/>
Rule 2	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 2	Rearm 0	<input \$1\"="" %9i2='\"\$0\"' %9u1='\"\$1\""/' %9ul='\"\$0\"' set="" then="" type="text" value="if %9X2=\"/> <input type="checkbox"/>
Rule 3	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 2	Rearm 0	<input \$1\"="" %9x4='\"0000\""/' set="" then="" type="text" value="if %9X4=\"/> <input type="checkbox"/>
Rule 4	Enable <input type="button" value="Y ▾"/>	Status: Trig	Qual 0	Rearm 0	<input \$1\"="" %9u1='\"\$1\""/' set="" then="" type="text" value="if %9F3=\"/> <input type="checkbox"/>
Rule 5	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$2\"="" %9u1='\"\$1\""/' set="" then="" type="text" value="if %9F3=\"/> <input type="checkbox"/>
Rule 6	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$1\""="" type="text" value="if %9V1<<%9UO then set %9U1=\"/> <input type="checkbox"/>
Rule 7	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$1\"="" %9uc='\"\$5\""/' set="" then="" type="text" value="if %9I5=\"/> <input type="checkbox"/>
Rule 8	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 60	Rearm 0	<input \$1\"="" %9t1='\"0060\"' %9u1='\"\$1\""/' set="" type="text" value="if %9V1<<%9UO then set %9X1=\"/> <input type="checkbox"/>
Rule 9	Enable <input type="button" value="Y ▾"/>	Status: Trig	Qual 600	Rearm 0	<input \$1\"="" %9ub='\"\$0\"' %9uh="%950" %9uj='%951"/' set="" then="" type="text" value="if %9I1=\"/> <input type="checkbox"/>
Rule A	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input 1\""="" type="text" value="if %9UH==%950 and %9UJ==%951 then set %9UB=%9UB+\"/> <input type="checkbox"/>
Rule B	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$0\"="" %9i1='\"\$0\"' %9u1='\"\$1\""/' and="" set="" then="" type="text" value="if %9UB=>%9UA and %9X1=\"/> <input type="checkbox"/>
Rule C	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$0\"="" %9i5='\"\$0\"' %9u1='\"\$1\""/' %9uc='\"\$3\"' and="" set="" then="" type="text" value="if %9X1=\"/> <input type="checkbox"/>
Rule D	Enable <input type="button" value="Y ▾"/>	Status: Trig	Qual 0	Rearm 0	<input \$0\"="" %9i5='\"\$0\"' %9wc='\"\$1\""/' and="" set="" then="" type="text" value="if %9X1=\"/> <input type="checkbox"/>
Rule E	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$1\"="" %9wc='\"\$0\""/' set="" then="" type="text" value="if %9X1=\"/> <input type="checkbox"/>
Rule F	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$1\"="" %9wc='\"\$0\""/' set="" then="" type="text" value="if %9I5=\"/> <input type="checkbox"/>
Rule Z	Enable <input type="button" value="Y ▾"/>	Status: Active	Qual 0	Rearm 0	<input \$0\"="" %9u2='\"\$0\"' %9u3='\"\$0\"' %9u4='\"0000\""/' or="" type="text" value="if %9U1=\"/> <input type="checkbox"/>

Message 0	<input type="text" value="%901;%931;#D1;%911-%912-%913%9UL-%914%916%917%9180%9F3%9X3%9WC--N%9UC;%9V1;%9V2;%9V5;%9L7....."/>	<input type="button" value="Submit"/>
Message 1	<input type="text"/>	
Message 1	<input type="text"/>	
Message 3	<input type="text"/>	
Message 4	<input type="text"/>	
Message 5	<input type="text"/>	
Message 6	<input type="text"/>	
Message 7	<input type="text"/>	<input type="button" value="Submit"/>

[Home Page](#) [Console](#)

Console Command Page:



MastMinder F400e

Site Name: GTAT Site 102

Console Command	<input type="text"/>	<input type="button" value="Submit"/>
<u>Response:</u>	Mastminder F400e Ready	

[Home Page](#) [Rule Settings](#)

The Console command page can be used to issue F400e local console commands to set or read any parameters not displayed in the other two web pages.

12. System Console Port


A system console is provided to allow management of the remote site unit via a locally connected RS232 serial terminal (e.g. PC running HyperTerminal)

12.1 Local terminal connection

A local serial terminal may be connected to the RS232 port 1.

Serial port 1 is available for use as a local console port at any time.

The communications format is fixed to 9600bps, no parity and 1 stop bit.



12.2 Console Port Commands

Once connected, the system console will respond with the prompt:

[Enter Password:](#)

(if an admin password has been set)

[<Site ID> <Version> :](#)

(if no password has been set, or when the correct password has been entered)

e.g.

[Mastminder 1.14 :](#)

12.2.1 Console Command Reference

The following commands are available through the console port.

Command get
Description Displays the value of one or more system parameters
Syntax get ppp,[ppp],[ppp]

Response <parameter value>
[<parameter value>]

Where ppp = parameter ID

Command getm
Description Displays the value of 20 consecutive system parameters
Syntax getm ppp

Response ppp=<parameter value>
ppp=<parameter value>
ppp=<parameter value>
...
ppp=<parameter value>

Where ppp = parameter ID

Command set
Description sets the value of a system parameter
Syntax set ppp=ddd

Response None (prompt)

Where ppp = parameter ID and ddd = new parameter data to set.


Command logout
Description Logs the current user off
Syntax logout

Response Enter Password:

An automatic logout will occur if no console commands are received for more than 30 minutes.

13. F400e Master Unit Connections – generic

The diagram below shows the connections to the I/O Module installed in the Generator.



14. F400e Master Unit Connection Schedule – generic

F400e Terminal	Description	Destination	Destination Terminal	Wire Colour
4	Generator Running Signal	Gen I/F Module	RY	
5	Generator On Load Signal	Gen I/F Module	LD	
6	Grid On Load Signal	Gen ATS auxiliary	Aux contactors on ATS	
11	Emergency Stop	Emergency Stop	Emergency Stop Switch	
12	Ground	Gen I/F Module	GD	
16	Generator Remote Start	Gen Connector	Remote Start on Gen	
18	Generator Remote Start	Gen Connector	Remote Start on Gen	
21	Fuel Sensor Ground	Fuel Sensor	Green & Pink	
22	Fuel Sensor Signal	Fuel Sensor	White	
23	Fuel Sensor +ve Power	Fuel Sensor	Brown	
24	12 volt power +ve	Generator battery	+ve (via fuse)	
25	12 volt power -ve ground	Generator battery	-ve	